




Hydrogeology Concepts and Considerations for RCW 90.94 Streamflow Restoration in WRIA 10 & 12

January 2019

Tom Culhane
Washington State Department of Ecology
Tom.Culhane@ecy.wa.gov




- All pore spaces (openings) below the water table are full of groundwater
- Tops of water tables generally mimic surface topography, and fluctuate seasonally and from year to year



USGS Water Science School

Under natural conditions, groundwater moves from areas of recharge to areas of discharge at springs or along streams, lakes, and wetlands





USGS Water Science School

Aquifer -- saturated geologic material permeable enough to yield economical quantities of water

Aquitard -- saturated geologic material with low permeability; well yields low; also called “confining layer”


Confined Aquifer -- saturated material below aquitard permeable enough to transmit useful water quantities





EXPLANATION


-  High hydraulic-conductivity aquifer
-  Low hydraulic-conductivity confining unit
-  Very low hydraulic-conductivity bedrock
-  Direction of ground-water flow





EXPLANATION

-  High hydraulic-conductivity aquifer
-  Low hydraulic-conductivity confining unit
-  Very low hydraulic-conductivity bedrock
- ① Local ground-water subsystem
- ② Subregional ground-water subsystem
- ③ Regional ground-water subsystem



Vashon
Glaciation
lasted
about
19,000 to
16,000 BP



Pierce County Geology





Groundwater – Surface Water Relationships



USGS Circular 1186

Spokane River losing Reach between Post Falls and Greenacres (Barker Road)



USGS Circular 1186




Figure 10. Seepage gains and losses measured during the seepage runs in August 1998 (A), September 1998 (B), and September 2012 (C), South Fork Nooksack River Basin, northwestern Washington.

Source: USGS SIR 2014-5221





Figure 9. Seepage reaches (A–R) during seepage runs in August and September 1998 and September 2012, South Fork Nooksack River Basin, northwestern Washington.

There can be gaining and losing reaches within same stream or river, and that relationship can change during the year

Magnitude of gains and losses can fall within measurement error of individual flows, making things harder to interpret


Baseflow: component of streamflow derived from groundwater inflow or discharge.



USGS Circular 1186


Baseflow is important for both water quantity and temperature.

Note: vertical
axis presented
in log scale




Baseflow
maintains
summer
streamflow
throughout most
of Washington


Percent of February Streamflow Supplied by Groundwater



In Washington groundwater baseflow contributes 68% of total annual flow for 594 studied gages (WSB 60)


Percent of August Streamflow Supplied by Groundwater





When well is drilled into a confined aquifer and water level rises above the confining unit, the well is referred as an artesian well. If water flows out of well at land surface it is referred to as artesian flowing well.

Pumping a well forms a cone of depression



Unconfined

Confined



Heath, 1983

Pumping groundwater from a well (conservation of mass) always causes...

- (1) decline in groundwater level (head) at and near the well, and
- (2) diversion to the pumping well of groundwater that was moving slowly to its natural, possibly distant, area of discharge.

Groundwater pumping can generally deplete streamflow in two ways:


- **Groundwater capture** - interception of groundwater flow that is tributary to a stream. This effect usually continues after pumping ends.
- **Induced streambed infiltration** - groundwater pumping pulling surface water from a stream toward a well.



Groundwater Velocities are Generally Low

- Groundwater movement normally occurs as slow seepage through pore spaces in unconsolidated earth or networks of fractures and solution openings in consolidated rocks.
- A velocity of 1 foot per day or more is a high rate of movement, and velocities can be as low as 1 foot per year or decade.
- By contrast streamflow velocities generally are measured in feet per second. A velocity of 1 foot per second equals about 16 miles per day.


Groundwater travel time is not an indication of the speed at which pumping effects propagate



With regard to water rights and surface water availability in Washington, concerns usually involve...

CLOSED

or



WRIAs 10 & 12

Hydrogeology

Significant WRIAs 10 & 12 Hydrogeology Studies

Hydrogeologic Framework, Groundwater Movement, and Water Budget in the Chambers-Clover Creek Watershed and Vicinity, Pierce County, Washington, USGS Scientific Investigations Report (SIR) 2010-5055 (Savoca, et al., 2010)

Numerical Simulation of the Groundwater-Flow System in the Chambers–Clover Creek Watershed and Vicinity, Pierce County, Washington, USGS SIR 5086 (Johnson, et al., 2011)



Hydrogeologic Framework, Groundwater Movement, and Water Budget in the Puyallup River Watershed and Vicinity, Pierce and King Counties, Washington, SIR 2015-5068, (Welch, et al., 2015)



Chambers-Clover Technical Assessment, Final Report. 2003 report prepared for Tacoma-Pierce County Health Department by consultants with assistance of Chambers-Clover Planning Unit



Puyallup watershed hydrostratigraphic and geologic units.

Period	Epoch	Hydrogeologic units defined in this study	Geologic units (from K.G. Troost, U.S. Geological Survey, written commun., 2008)	Geologic units in Schasse (1987) and Walsh (1987)	Hydrostratigraphic units in Robinson & Noble, Inc., and others (2003)	Stratigraphic units
Quaternary	Holocene, Pleistocene	AL1 upper alluvial aquifer	Qal, af, Qp	Qa,	Aquifer A: includes Steilacoom gravel, Vashon Till, Vashon advance outwash, Esperance Sand	Recent Holocene alluvium
		MFL confining unit		Qvl(o), Qvl(e)		Volcanic mudflow-lahar deposits
		AL2 lower alluvial aquifer				Older Holocene alluvium and ancient deltaic deposits beneath MFL within major river valleys (Dragovich and others, 1994)
		A1 aquifer	Qal, Qv, Qvr, Qvry, Qvs, Qw	Qa, Qgd, Qgo, Qgog, Qgos, Qp		Vashon Drift (Steilacoom gravel, recessional outwash)
		A2 confining unit	Qvt, Qvi, Qvrl	Qgm, Qgt, Qgl		Vashon Drift (till, moraine, recessional ice-contact, and lacustrine deposits)
		A3 aquifer	Qva, Qpfc	Qga		Vashon Drift (advance outwash)
		B confining unit	m, af, Qal, Qb, Qf, Qls, Qns, Qob, Qpdc, Qpf, Qpoc, Qpon, Qtf, Qvlc, Qwbc	Qc(k)	Layer B	Olympia Beds (Kitsap Formation), Lawton Clay
		C aquifer	Qpog, Qpogc	Qgp	Aquifer C	Salmon Springs Drift, Penultimate Drift, Hayden Creek Drift, Wingate Hill Drift
		D confining unit			Layer D	Puyallup Formation
		E aquifer			Aquifer E	Stuck Drift
		F confining unit			Layer F	Alderton Formation
		G undifferentiated deposits			Aquifer G	Orting Drift and older deposits
Tertiary	Miocene to Eocene	Bedrock unit		Qap, Qap(h), Qapt(h), Qap(wh), Qapt(wh), and all pre-Quaternary deposits		Basement confining unit and some alpine glacial deposits


From USGS Puyallup River Watershed hydrogeologic characterization (USGS SIR 2015-5068)







From USGS Chambers-Clover Creek watershed hydrogeologic characterization (USGS SIR 2010-5055)



EXPLANATION

Hydrogeologic unit



AL	AL Alluvial valley aquifer	A3	A3 Aquifer	D	D Confining unit	G	G Undifferentiated deposits (Note: not at land surface)
A1	A1 Aquifer	B	B Confining unit	E	E Aquifer	Br	Bedrock
A2	A2 Confining unit	C	C Aquifer	F	F Confining unit		

EXPLANATION

Hydrogeologic unit


AL	AL Alluvial valley aquifer	A3	A3 Aquifer	D	D Confining unit	G	G Undifferentiated deposits (Note: not at land surface)
A1	A1 Aquifer	B	B Confining unit	E	E Aquifer	Br	Bedrock
A2	A2 Confining unit	C	C Aquifer	F	F Confining unit		

USGS SIR 2010-5055



Sequence in USGS SIR 2010-5055
indicating extent of all eight aquifers
(youngest to oldest)

Unit: AL alluvial valley aquifer




USGS SIR 2010-5055

Unit: A1 aquifer




USGS SIR 2010-5055

Unit: A2 confining unit




USGS SIR 2010-5055

Unit: A3 aquifer




USGS SIR 2010-5055

Unit: B confining unit




USGS SIR 2010-5055

Unit: C aquifer




USGS SIR 2010-5055

Unit: D confining unit




USGS SIR 2010-5055

Unit: E aquifer




USGS SIR 2010-5055

Unit: F confining unit




USGS SIR 2010-5055

Unit: G undifferentiated
deposits



USGS SIR 2010-5055

Grid with 1,000 by 1,000
feet cells for Chambers–
Clover Creek watershed
groundwater-flow system
numerical simulation
(Johnson, et al., 2011)




Model Simulation	Recharge (precipitation and return flows)	Withdrawal amount (public and residential)	Withdrawal location
Simulation 1 Steady-State	Decrease precipitation recharge by 20 percent	No change	No change
Simulation 2 Steady-State	Increase return flows by 15 percent	Increase public and residential withdrawals by 15 percent	No change
Simulation 3 Steady-State	Increase return flows by 15 percent	Increase public and residential withdrawals by 15 percent	Deepen all public and residential withdrawals
Simulation 4 Steady-State	Increase return flows by 15 percent	Increase public and residential withdrawals by 15 percent	Deepen only group A public withdrawals
Simulation 5 Transient	Increase monthly return flows by 15 percent	Increase monthly public and residential withdrawals by 15 percent	No change
Simulation 6 Transient	Increase monthly return flows by 15 percent	Increase monthly public and residential withdrawals by 15 percent	Deepen only group A public withdrawals during summer months

USGS SIR 2010-5055

USGS 12101500 PUYALLUP RIVER AT PUYALLUP, WA

Flow exceedance Probability Hydrograph


Period of Record: 1915 - 2019



RCW 90.94 Considerations

RCW 90.94 Planning Groups must describe Future Permit-Exempt Well Consumptive Use over Next 20 Years

- Ecology recommends relying on more than one method for estimating numbers of future wells including: population projections, historic building permit data, and/or historic well log drilling rates.
- To account for portion of water not consumptively used, water use estimates can be adjusted to account for water that will not return to hydrologic system.



From Ecology ESSB 6091 Streamflow Restoration Water Use Estimate Recommendations

Household Consumptive Indoor Water Use (HCIWU):

60 gpd X 2.5 people per house X 365 days X 0.00000307 AF/gal. X 10%₁ cons. use = 0.017 AF/YR

Household Consumptive Outdoor Water Use (HCOWU):

	May	June	July	August	Sept.	Total
<u>Irrig. requirements</u> (in.) ₂	0.63	2.72	4.11	2.75	0.90	11.11

Assuming outdoor watering area of 0.4 acre:

Irrigation Requirements (in.) = 11.11 inches/12 inches per foot X 0.4 acres = 0.37 AF/YR

Factoring in assumed application efficiency of 75 percent,

0.37 acre-feet ÷ 75% application efficiency = 0.49 acre-feet

Factoring assumed outdoor water use consumption of 80%:

0.49 acre-feet x 80% consumed (20% return flow) = 0.39 acre-feet

Basin-wide Household Consumptive Water Use (BHCWU):

Consumptive water use by future permit-exempt domestic wells for WRIA or subbasin:

BHCWU = number of houses served by permit-exempt domestic wells X (HCIWU + HCOWU)

1. Assuming all houses discharge wastewater via septic systems

2. From Appendix A of the Washington Irrigation Guide (WAIG) (U.S. Department of Agriculture, 1997)


When & Where Consumptive Use Impacts Will Occur

- RCW 90.94 requires high priority offset projects to replace 20-year water use in-time and in same subbasin.
- Estimating timing of groundwater impacts on streams with precision is complicated due to lags between when a well is pumped and when those impacts propagate to a stream.



Need to Simplify

Due to hydrogeologic variability, uncertainty regarding new well locations, limited money, and limited time, planning groups will not be able to model pumping effects in detail.



Conceptual Groundwater Understanding


Conceptual groundwater models provide overall hydrogeologic understanding.

In water resources terms this generally considers:

- spatial delineations of recharge and discharge areas
- identification of pathways from unsaturated zones through saturated zones to groundwater receptors
- analyses and estimates of time scales of flow and effects of groundwater pumping

Seasonal vs. Steady State

- Magnitudes of aquifer pumping pulses decay over distance and time as effects spread out.
- In this example water-level changes range from a distinct pump-on – pump-off pattern, to a relatively constant impact.
- In most instances in western Washington it is reasonable to assume streamflow depletion will essentially be steady state - especially beyond distance of few thousand feet.




Spatial Considerations

- Even when planning groups assume steady state conditions, they will need to consider how steady state pumping effects are distributed spatially.
- Conceptually, one option is to assume all pumping effects will remain within a subbasin and be distributed evenly to all surface water bodies.
- In those instances where most future wells are likely to be shallow and congregated near a stream particularly important to fish, another option would be to conservatively assume depletion impacts are entirely attributed to streams closest to pumping well.


Significance of Scale

When evaluating the hydrologic impacts of new permit-exempt domestic wells or water offset projects on surface water an important consideration is what the magnitude of impacts or benefits will be relative to size of the water bodies.



Context of RCW 90.94

- Structure of mitigation under RCW 90.94 is fundamentally different than mitigation for groundwater permits.
- Typically water right permits require offsetting impacts of groundwater pumping in-time and in place.
- RCW 90.94 allows mitigation for permit-exempt domestic wells to occur anywhere within a WRIA, provided watershed plans achieve a Net Ecological Benefit (NEB).
- Per RCW 90.94 when Ecology reviews plan addendums it will be looking for:
 - (1) “actions that the planning unit determines to be necessary to offset potential consumptive impacts to instream flows associated with permit-exempt domestic water use.”
 - (2) actions that “will result in a net ecological benefit to instream resources within the water resource inventory area.”
- This means placing offset projects in places most beneficial to fish is probably more important than understanding specific impacts from permit-exempt domestic well pumping.



Questions?

Tom Culhane
Washington Department of Ecology
Tom.Culhane@ecy.wa.gov